

LOWRANCEPoint-1 Antenna





Attention!

The Point-1 antenna contains a heading sensor and should not be mounted within 1 meter (3.3 ft) of any potential magnetic source.

Potential sources for magnetic/electromagnetic interference include:

- Electrical Motors/Magnets (A)
- Outboard Engines (B)
- High current electrical sources such as main power cables, batteries, distribution panels etc.

